



2) Rod - non-conductive

(drop lead)

Instruction includes methods of montage:





MULTI-A - MULTI-B extrusion

Tools needed for mounting:

- drill
- pliers
- allen wrench
- soldering iron

WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly. More methods and related accessories can be found at www.klusdesign.eu



MULTI-A and MULTI-B - suspended fixture mounting instructions 1. Rod - conductive driven power supply

*If fully built fixtures are ordered and received from KLUS please skip to #3





MULTI-A and MULTI-B - suspended fixture mounting instructions 2. Rod - non conductive (requires drop lead)

*If fully built fixtures are ordered and received from KLUS please skip to #3

