


Parts needed to mount the BZP-ZO conductive head




Tools needed for mounting:

- allen wrench
- drill


NOTE! A list of products corresponding with the selected accessories is available at www.KlusDesign.eu

1. Drill a 5mm diameter hole in the selected extrusion.




5 mm


2. Bevel the hole so that the plastic screw head fits in.




3. Mount the plastic screw (B), the plastic base (C) and the head (D).



4. Mount the LED strip and run the cable (A) through the plastic screw and the head



5. Mount the arm in the head (D). It must press the power cable. Block the arm by tightening the pressure screw in the head with the Allen wrench.



10. NOTE! The position of the lighting fixture on the arm can be adjusted in the range of 360° (depending on the distance of the fastener from the edge of the extrusion).

